

Congratulations on Your Purchase

of the ClearView Window Bird Feeder

Component List:

Top and Bottom PVC Plates
Left and Right Slide Panels
Clear Feeder Viewing Sheet

Feeder Filling Port Cap
Assembly Rod with Decorative Nut
Installation Foam & Adhesive Weather Strip

Please follow these general guidelines for . . .

Assembly:

- Place the bottom plate on a level surface with the groove facing up
- Peel the protective coverings from all edges of the viewing sheet
- Starting from one side of the groove, insert the clear feeder viewing sheet into the bottom plate (ensure that attached trim faces outward)
- With the groove facing downward, align the top feeder plate with the clear feeder viewing sheet. Start from one side of the groove and adjust the viewing sheet as necessary when installing the top plate.
- Insert the assembly rod from the bottom plate through the top plate, tightening the decorative nut onto the rod to secure the feeder plates together
- Fully remove the protective coverings from the clear viewing sheet
- Slide the left and right panels onto the feeder plates (ensure that the panel is oriented so that the panel groove closest to the edge is at the top of the feeder)
- Insert the filling port cap into the top feeder plate

Placement:

- Choose a window in a room away from prevailing weather direction
- Choosing a window away from heavy foot traffic and bright room lighting will help encourage visits from skittish birds
- Choose a window at least 5'-6' from ground level to discourage squirrels from using the feeder

Installation:

- This feeder is designed to be installed in most single and double hung windows between 30"-36" wide
- With the window open, center the feeder in the window opening with the feeder slide panels facing the outside
- Extend the left and right slide panels to the outside of the window frame (if possible, use the window track to help secure the feeder)
- Lay the adhesive weather strip across the top of the feeder panels and trim to length
- Remove any dust or debris from the tops of the slide panels and adhere the weather strip by removing the adhesive covering and pressing firmly onto the panels
- Close the window down onto the weather strip
- Tuck the installation foam into any gaps that exist between the window frame and the feeder
- For customers with windows that do not feature window stops, installing a wooden dowel rod (not included) between the top of your window and window frame will prevent the window from opening and dislodging the feeder